


# Electric Monorail Mover

## Remote and Manual Control



B1: Garden Cart Battery: Sears Die Hard Gold: 7.75"x5.188"x7.312"

S1: SPST Push Pull Switch: NAPA PP6021: On/Off

S2: SPST Momentary NO: NAPA STB6032: Manual Start Forward

S3: SPST Momentary NO: NAPA STB6032: Manual Stop Reverse

F1: Fuse 1: 30A

R1: 100 ohm Resistor 1/4 watt: Braking Speed

D1 - D7: Diode: Isolation

RR1 - RR2: Reed Relay NC: Remote Stop

ER1: 12V SPST Relay 25A: Motor On/Off

ER2: 12V SPST Relay 25A: Forward/Reverse

